



Assembly: Use the #6 x 1" screws (provided) to screw the uprights in place. Insert the slats into the slot in the proper order.

